


584 Flex-Check Valve Head Loss Chart



SIZE	2	2 1/2	3	4	6	8	10	12	14	16	18	20	24	30	36	42
Cv	95	155	225	440	1,040	1,900	3,050	4,600	6,600	8,700	11,200	14,200	21,000	33,500	50,000	68,000